

New: SNR rear suspension kits

NEW

Why rear suspension kits ?

- To meet a high demand on the market
- They complement our range of front suspension kits

Description:

- Rubber bush and/or rear shock absorber attachment
- Reduces vibrations
- Ensures suspension efficiency and safety

Special characteristics:

- No bearings, only metal and rubber parts.

Characteristics:

- Easy to change when replacing the shock absorber
- No special tools

**For your safety,
Replace rear suspension kit during
replacement of the shock absorber**



REAR SUSPENSION KITS

- The SNR range fits most vehicles on the market which use this type of suspension.

KB	Make	Applicable to
KB674.00	HONDA / ROVER / MG	Accord, Civic, Crx, Crv, Integra, Odyssey, Shuttle, 25, 45, 200, 400, ZS, ZR
KB950.00	BMW	3 Series (E 30 - E 36 - E 46 - Z3)
KB950.01	BMW	5 Series (E 39) saloon
KB950.02	BMW	5 Series (E 39) touring
KB950.03	BMW	5 Series (E 39) controlled suspension
KB950.04	BMW	5 Series (E 39) sports chassis, 7 Series (E 38)
KB950.05	BMW	5 Series (E 34)
KB950.06	BMW	7 Series (E 32)
KB952 .00	FORD	Fiesta 4, Ka, Puma
KB952.01	FORD	Mondeo, Cougar
KB952.02	FORD	Fiesta 5, Fusion
KB952.03	FORD	Focus II, Cmax
KB955.00	RENAULT	Twingo
KB955.01	RENAULT	Safrane
KB957.00	VAG	Cordoba, Golf 2, Golf 3, Ibiza, Polo 5, Polo 6, Toledo1, Vento, Golf II convertible, Golf III convertible, Jetta II, Corrado
KB957.01	VAG	100, A6, 200
KB957.03	VAG	Golf 4, A2, Cordoba, Ibiza, Leon, Toledo, Bora, Polo 7, Skoda Octavia, Roomster
KB957.04	VAG	Golf 4, New Beetle, Polo, Fox, Cordoba, Ibiza, Leon, Toledo, Skoda Octavia, Fabia
KB957.05	VAG	80
KB957.06	VAG	A6, Passat 5, Passat 6 (saloon)
KB957.07	VAG	Golf 5, Altea, Toledo, Leon II
KB957.08	VAG	Golf 5, A3
KB958.00	FIAT	Fiorino, Innocenti Elba, Mille (vehicule initially manufactured by Fiat Brazil and renamed for the Italian market.)
KB958.01	FIAT	Uno, Duna, Penny, Innocenti Mille Clip
KB958.02	FIAT	Croma, Thema
KB958.03	FIAT	Alfa 164, Croma, Kappa, Thema
KB959.00	PEUGEOT	406 except coupé
KB959.01	PEUGEOT	307

Recommendation:
Replace rear suspension kit when
replacing the shock absorber.

